

INSTRUCTION MANUAL

Repair Joints under pressure while
the system is ON

Magicawrap- Tape (L Set)

Product	Dia. of pipe to apply
MTRL 25-5	upto 25 mm
MTRL 40-5	upto 40 mm
MTRL 50-5	upto 50 mm
MTRL 65-5	upto 65 mm
MTRL 75-5	upto 75 mm
MTRL 100-5	upto 100 mm
MTRL 125-5	upto 125 mm
MTRL 150-5	upto 150 mm

Pressure: Basically 0.5MPa (5Kg/cm²) or under

Please read this document before you start work to make sure that it will be safe and effective.

Requirements for use:

- Warranty period shown on the aluminum foil package.
- Store the package in cool, dry and shaded area
- No incidents nor consecutive damages are indemnified unless the products are determined defective by our quality standard.
- Wrong or misuse is not indemnified. (User shall determine suitability of products for use and assumes all risk)

Product Configuration

Product	Magicawrap	Magicawrap-Tape	Ori-Steel	Latex Gloves
MTRL 25-5	MT-205 1pc	L type 25-5 1pc	1 cut	1 set
MTRL 40-5	MT-205 1pc	L type 40-5 1pc	1 cut	1 set
MTRL 50-5	MT-309 1pc	L type 50-5 1pc	1 cut	1 set
MTRL 65-5	MT-309 1pc	L type 65-5 1pc	1 cut	1 set
MTRL 75-5	MT-415 1pc	L type 75-5 1pc	1 cut	4 set
MTRL100-5	MT-415 1pc	L type 100-5 1pc	1 cut	4 set
MTRL125-5	MT-420 1pc	L type 125-5 1pc	1 cut	4 set
MTRL150-5	MT-430 1pc	L type 150-5 1pc	1 cut	4 set

Orihara Manufacturing CO., LTD.
1-3-3, Nishinipori, Arakawa-ku, Tokyo, JAPAN
TEL +81-3-56040303 FAX +81-3-56040304

Recommendable Use.

- You can repair under pressure pipes while the system is ON.
* Please select the most suitable package depending on the pipe diameter for repair.
- Effective for wide range of pipe material:
Steel, Stainless, Copper, Plastic, Polypropylene, Polyethylene, Lead etc.

WARNING (for your Safety)

- When winding **Magicawrap-Tape** (pressure sealing rubber tape) around the pipe, see instructions on **Magicawrap-Tape**.
 - **DO NOT** touch **Magicawrap** with your bare hands. Avoid direct contact to your unprotected skin or eyes. **Be sure to use a pair of protective Latex gloves for handling of Magicawrap.** The resin pre-impregnated in **Magicawrap** will adhere to skin and clothing and may cause skin irritation.
 - In case you have touched **Magicawrap**, wipe out lightly with alcohol or rinse with soap and water for more than 5 minutes.
 - If eyes are exposed to the resin, rinse eyes with water for 15 minutes and then contact a doctor.
 - Any tools contaminated with the resin of **Magicawrap** can be cleaned with alcohol or acetone prior to curing.
-
- **DO NOT** Open the package of **Magicawrap** until you start applying as moisture in the air will activate the resin in **Magicawrap**
Please apply the entire roll of **Magicawrap**, as unused **Magicawrap** will be hardened.