

INSTRUCTION MANUAL

Repair Non-pressure Straight Pipes

Magicawrap S



Magicawrap S is suitable for pipe repair of no leakage

(On any leakage area, use Magicawrap-Tape Set).

rubber patch in the package is effective for crack, hole of the pipe. First, affix the rubber patch on crack or hole

Please read this document before you start work to ensure that it will be safe and effective.

Requirements for use:

- Warranty period is shown on the **aluminum foil package**.
- Store the package in cool, dry and shaded area
- No incidents nor consecutive damages are indemnified unless the products are determined by our control standard.
- All defective products shall be replaced with new ones.
- Wrong or misuse is not indemnified. (User shall determine suitability of products for use and assumes all risk)

Product Configuration

Product	Magicawrap	Rubber Patch	Latex Gloves
MT-205S	MT-205 1 pc	25x90L 1 pc	1 set
MT-309S	MT-309 1 pc	25x120L 1 pc	1 set
MT-415S	MT-415 1 pc	25x150L 1 pc	1 set
MT-420S	MT-420 1 pc	25x200L 1 pc	4 set
MT-430S	MT-430 1 pc	25x400L 1 pc	4 set
MT-440S	MT-440 1 pc	25x600L 1 pc	4 set
MT-450S	MT-450 1 pc	25x1000L 1 pc	4 set

Orihara Manufacturing CO., LTD.

1-3-3, Nishinipori, Arakawa-ku, Tokyo, JAPAN

TEL +81-3-56040303 FAX +81-3-56040304

Recommendable Use.

- Please select the most suitable package depending on the pipe diameter for repair.
- Effective for wide range of pipe material:
Steel, Stainless, Copper, Plastic, Polypropylene, Polyethylene, Lead etc.

*This is for Water Pipe only. For hot water, steam, oil, chemical liquid, please ask your local distributor for most suitable Patch.

WARNING (for your Safety)

- **DO NOT touch Magicawrap with your bare hands. Avoid direct contact to your unprotected skin or eyes. Be sure to use a pair of protective Latex gloves for handling of Magicawrap. The resin pre-impregnated in Magicawrap will adhere to skin and clothing and may cause skin irritation.**
- **In case you have touched Magicawrap, wipe out lightly with alcohol or rinse with soap and water for more than 5 minutes. Contact a medical doctor as required.**
- **If eyes are exposed to the resin, flush eyes with water for approx. 15 minutes and then contact a doctor.**